TROUBLESHOOTING:

	Possible Cause	Corrective Action
Bulb will not light	1. Bulb is burned out	1. Replace light bulb
	2. Switch is off	2. Make sure switch is on
	3. Faulty wire connection	3. Check wiring
Fuse blows or circuit breaker trips when light is turned on	Crossed wires or power wire is grounding out	Check wire connections

PRODUCT MAINTENANCE:

1. To clean the outside of the lamp, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the shade and surface of the lamp.

2. To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the inside shade and interior surface of the fixture.

3. Do not use any cleaners with chemicals, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

LIMITED WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor expense costs involved in the replacement or repair of said product.**

INSTRUCTION MANUAL

INTERIOR 16-LIGHT CHANDELIER
ALLURE

HOME DEPOT SKU 444-574 S/O 453-649 (UPC 773546170444)
ANTIQUE SILVER FINISH



Thank you for purchasing this Hampton Bay interior decorative lighting. This product has been manufactured with the highest standards of safety and quality.

FEATURES:

Extravagant and sophisticated, this hanging light hearkens back to glorious Hellenistic days, with dangling strands of precious metal, finished with leafy boughs.

QUESTIONS, PROBLEMS, MISSING PARTS:

Before returning to you local Home Depot, please call our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference you **SKU # (444-574) or UPC # (773546170444)**.

CAUTION:

1. Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

2. CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.

3. If you have any non-electrical question about this fixture, please contact our Customer Service Team at 1-877-527-0313 or visit www.homedepot.com. Please reference your **SKU# (444-574) or UPC# (773546170444).**

4. Keep your receipt and these Instructions for Proof of Purchase.

INSTALLATION:



ADDITIONAL PARTS FOR INSTALLATION (included):

2. Wire Nut (x3)

3. Brass Connector


28. Set Screws (x2)


27. Fixture Clamp

6. Lock Nut

7. Nipple


8. Canopy


9. Canopy Loop

10. Loop Ring

4. Star Washer

INSTALLATION INSTRUCTIONS:

1. Turn off power at main fuse box.
2. Remove loop ring (10) from canopy loop (9).
3. Hold chandelier up against canopy loop (9) with chain and adjust to desired height. Remove excess chain.
4. Before tightening chain onto canopy loop (9), weave chandelier wire through every second link.
5. Let the canopy loop ring (10) slip to the bottom of the chain. Repeat this step for canopy (8).
6. Connect the free end of the chain to canopy loop (9) by using hinge clip (29).
7. Align all wires through the chain loop, then place star washer (4), lock nut (6), nipple (7), lock nut (6), and star washer (4); put all wire through the brass connector (3) to complete junction assembly.
8. Install both ground wires of chandelier [one from the canopy (8) and one from the fixture] to ground screw or ground wire of junction box (1) or ground screw on cross bar.
9. Connect black wire of power supply to the smooth side of the wire (flexible cord) from the chandelier and connect white wire of power supply to the ribbed side of the wire from the chandelier.

NOTE: Always use wire nuts (2) or marrattes (included) to connect wires and push all excess wire and connections back into junction box (1).

10. Install air craft cable through junction box (1) to structural member, and then connect cable to the fixture clamp secure, installation with set screws (28).
11. Lift canopy (8) up to ceiling covering junction box (1) and secure by using canopy loop ring (10).

TOOLS REQUIRED FOR ASSEMBLY & INSTALLATION (not included):

Safety Goggles


Wire Strippers


Wire Cutters


Flathead Screwdriver


Phillips Screwdriver

Electrical Tape

Ladder

B10 Bulb 60W max. (not included) (x16)

ADDITIONAL PARTS FOR ASSEMBLY (included):

11. Chain Loop

12.Center Nut

13. Cap (x2)

14. Decorative Spacer

16. Top Nipple with Lock Nut


17. Candle Sleeve

18. Floral Bobeche

19. Decorative Bobeche

20. Decorative Crystal Drop

21. Decorative Crystal (A)


22. Bottom Nipple with Lock Nut


23. Decorative Finial

24. Lower Decorative Assembly

25. Decorative Crystal (B)

26. Decorative Crystal (C)

26. Hinge Clip (x2)

ASSEMBLY INSTRUCTIONS:

1. Carefully unpack the fixture; Layout all parts on a clean surface.

2. Install bottom nipple with lock nut (22) onto the base of the fixture main body.

3. Place lower decorative assembly (24) on the bottom nipple with lock nut (22) and tighten with decorative finial (23).

4. Install top nipple with lock nut (16) onto the hub of the fixture main body.

5. Place top decorative assembly (15) on the top nipple with lock nut (16).

6. Insert cap (13), decorative spacer (14) and cap (13), on the top nipple with lock nut (16).

7. Secure assembly by tightening center nut (12) to the top nipple with lock nut (16).

8. Tighten chain loop (11) onto top nipple with lock nut (16).

9. Connect the free end of the chain to the chain loop using the hinge clip (29).

GLASS AND BULB INSTALLATION:

1. Insert decorative bobeche (19) and floral bobeche (18) onto the fixture socket, then install candle sleeve (17).

2. Attach decorative crystals (A) (21) to the lower base of the fixture main body.

3. Attach decorative crystals (B) (25) to the mid section of the fixture main body.

4. Attach decorative crystals (C) (26) to the upper section of the fixture main body.

5. Attach decorative crystal drops (20) to the arms of the fixture main body.

6. Install 60W max B10 chandelier bulb (not included).

ASSEMBLY: